



Maxos, mounting accessories

9MX056 MB WH

Wspornik montażowy

The light line fulfils two functions: first, it provides a sturdy in-line mounting rail on which to fix the electrical units, and second, it provides a housing for the electrical cables that bring power to the units. For suspended light lines, the light-line sections are connected using the integrated electrical connector and a sturdy external mechanical coupling piece (accessory). Surface-mounted light lines use the same integrated electrical connector and an internal coupler (accessory). On the upper part of the light-line section, special knock-out openings enable cable entry wherever needed. The basic accessories of Maxos TL-D trunkings can also be used for the TL5 trunkings.

Dane produktu

Informacje ogólne	
Kąt	36 do 50°
Kolor akcesorium	Biel
Rodzina produktów	9MX056 [ACC MAXOS]

Mechanika i korpus	
Całkowita długość	30 mm
Całkowita szerokość	74 mm
Całkowita wysokość	45,3 mm
Wymiary (wysokość x szerokość x głębokość)	45 x 74 x 30 mm
Materiał	Stal

Zatwierdzenie i Aplikacja

Kod stopnia ochrony	-
Klasa ochrony IEC	-

Dane produktu

Full EOC	403073266188699
Nazwa produktu na zamówieniu	9MX056 MB WH
Kod zamówienia	66188699
Numerator - Quantity Per Pack	1
Numerator - Packs per outer box	20
Numer materiału (12NC)	910605143826
Pełna nazwa produktu	9MX056 MB WH
EAN/UPC - Opakowanie	4030732258666

Maxos, mounting accessories

