



Maxos, mounting accessories

9MX056 PB WH

9MX056 | ACC MAXOS - - - - - Łącznik boczny - - - - mm - - -
Biel - -

The light line fulfils two functions: first, it provides a sturdy in-line mounting rail on which to fix the electrical units, and second, it provides a housing for the electrical cables that bring power to the units. For suspended light lines, the light-line sections are connected using the integrated electrical connector and a sturdy external mechanical coupling piece (accessory). Surface-mounted light lines use the same integrated electrical connector and an internal coupler (accessory). On the upper part of the light-line section, special knock-out openings enable cable entry wherever needed. The basic accessories of Maxos TL-D trunkings can also be used for the TL5 trunkings.

Dane produktu

Informacje ogólne	
Kolor akcesorium	Biel
Rodzina produktów	9MX056 [ACC MAXOS]
Mechanika i korpus	
Materiał	Stal
Zatwierdzenie i Aplikacja	
Kod stopnia ochrony	-
Klasa ochrony IEC	-

Dane produktu	
Full EOC	403073267455899
Nazwa produktu na zamówieniu	9MX056 PB WH
Kod zamówienia	67455899
Numerator - Quantity Per Pack	1
Numerator - Packs per outer box	10
Numer materiału (12NC)	910680011026
Pełna nazwa produktu	9MX056 PB WH
EAN/UPC - Opakowanie	4030732276523